


**Products:** 491033 - Relay Board Assembly for 120v Rotisserie Smokers with a Cook and Hold Control and a Mechanical Door Switch

**Serial Range:** N/A

**Release Date:** September 1, 2016

### Relay Board Assembly:

This relay board will work with smokers equipped with a circuit breaker, or a shock relay for overcurrent protection.



For smokers equipped with a circuit breaker:

1. Connect the two yellow wires marked "CB" to the two prongs of the circuit breaker.

For smokers equipped with a shock relay:

1. Attach the jumper wire to the two yellow wires marked "CB".

**Additional Comments:**

This relay board will work with smokers with, or without, an interior light. If the smoker has an interior light attach the interior light wire to the grey wire on the relay board.

**Secondary Distribution:**

Service technicians within the Distributor's organization.

Service companies.

**For Additional Information:**

Southern Pride Technical Support: (800) 437-2679